

Trusting - 6068 - Kit de freno premontado

- Opel
- Trasero
- TRW
- Ø Tambor [mm]: 200
- Ancho Zapata [mm]: 45
- Ø Bombín [mm]: 19,05